



## Extension Hearing Aid Compatible

For those staff in practice that require hearing assistance the Yealink T41S comes with a hearing aid compatible handset fitted with an induction loop.

Coupled with the superb HD audio the call quality for staff with hearing loss will be optimised to assist them in their day to day telecommunications use.



## Choose Your Features

We understand that different roles within your surgery will often have distinct requirements from a telephone. The Hearing Aid Compatible Extension has 10 configurable keys allowing each handset to be finely tuned to the user's needs.

Whether the requirement is to broadcast to a PA system in Reception, to speed dial a commonly called telephone number or to set yourself into Do Not Disturb (DND) mode, having the ability to self configure each handset to benefit the working environment increases efficiency and usability.

Below are the configurable button options you are able to set.

Feature	Description
Busy Lamp(s)	Shows busy status of other extensions, users or distribution groups and allows single key dial or transfer
Login	Allows single key log in to reception group or hot desk login from a list of staff names
Pickup	Allows pickup of a call ringing on another extension in the group
Switch Device	Switch from desk phone to mobile with a single press of a button.
No Appointments	Insert a "No Appointments left today" announcement in the call flow with a single button press.
Step In	Step into a distribution group to assist with answering patient calls with a single press of a button.
DND	Put phone into Do Not Disturb (do not ring) to allow the completion of tasks or to make outbound calls without being targeted by inbound calls.
Page	Broadcast to other phones or via Tannoy system in reception (if available)
Record on/off	Suspend or resume call recording if configured for this user.
Directory	Allow access to the central directory via the telephone.



## High Definition Audio

Where available on both phones in the call, the phone uses the latest in Hi Fi phone audio, for maximum call quality and intelligibility.



## Standard Extension Full Specification

Phone	Yealink T41S
<b>Fixed Keys</b>	Last Number Redial Hold & Transfer On Hook Dial (Speakerphone) Volume Control Headset Activate Message Retrieval 3 Way Conference
<b>Soft Keys</b>	4 context sensitive keys showing relevant functionality when idle, on a call or on hold.
<b>Function Keys</b>	6 programmable function keys for handset optimisation.
<b>Display Options</b>	Phone name, logged in user name, user state and date and time information
<b>Login Options</b>	Can either be a personal extension with optional login/out for a single user or a hotdesk extension where the login process offers a list of hotdesk users to be selected from.
<b>Web Control</b>	Logged in user has access to the Surgery Connect Console or Configuration Console according to their role. Allows access to call recordings, history and preferences.
<b>Page</b>	Broadcast to other phones or via Tannoy system in reception (if available)
<b>General Features</b>	Distinctive ringing for internal, external or group calls. Desk or wall mounted